

User's Manual of Smart Watch



Thank you for choosing our smart watch. Please read this manual to fully understand the operation of the product. Usually, it is connected to a smart phone through Bluetooth. The smart watch has multiple practical functions and services for convenient use of your smart phone and some functions for your sports and health as well. This manual is subject to change without prior notice.

The smart watch is IP68-rated and can be worn in rain or when you are washing hands or swimming. However, do not wear it when taking a shower with warm water or having a sauna because it is not steam-proof. If water enters the smart watch because of your failure to follow this manual, we will not provide free repair. If there is water in the speaker hole, swing it out to make the sound normal again.

※ Operation instructions


Power button: Long press it to power on or off the smart watch or press it shortly to back to the standby page. If the smart watch has crashed, press this button for 10 seconds to restart it.

Back button: Press it shortly to return to the previous menu.


TP gestures: Swipe left on the screen to enter the heart rate mode or right to enter the main menu. When in a function, swipe right to go back or left to enter the next menu.

Dial switching: A dial selection page will appear after the time page is long pressed. Choose the desired dial and click 'OK'.

Status bar: Swipe down on the standby page to show the Bluetooth status, battery level, time, etc.



Charge: When charging the smart watch, turn it over and align the contact points of the charging cable. The charging cable is attracted to the smart watch by magnet. The PC USB port or 5V standard chargers for smart phone can be used to charge the smart watch. It can be fully charged in around 70 minutes.



Keep the two contacts of the charging cable from conductive objects to avoid burn because of short-circuiting.

Connect the smart watch to your smart phone: Download the 'Fundo' APP onto your smart phone and install it. There are two ways to do this as below.

A. IOS or Android smart phone user: Use your smart phone browser to scan the QR code (Setting-Download APP) on the smart watch or the following QR code and download the first option. Or enter the page through the 'Scan' function on WeChat, click the option at the upper right and choose to download through your smart phone browser.



B. Android smart phone user: Search 'Fundo' in the Application of Treasure and download it; Apple smart phone user: Search 'Fundo' in the App Store and download it.

Choose 'Agree' for each permission prompt during installation of the APP. The smart watch can realize all of its functions after connected via both Bluetooth 3.0 and Bluetooth 4.0.

Connection of Bluetooth 4.0: After the APP is installed, start it and enable the smart phone Bluetooth. The APP will then give a prompt to enable notification. Click 'OK'. Click 'More' at the lower right to enter the device adding page. On the time interface, swipe down the status bar, click the Bluetooth icon to enable Bluetooth. Search the smart watch and click 'Connect' on your smart phone. For some Android smart phones, the watch's name can be searched after the GPS is enabled.

Connection of Bluetooth 3.0: Enter the main menu of the smart watch, search the desired Bluetooth device name under the 'Bluetooth' menu, choose 'Enable Bluetooth', click the desired smart phone

Bluetooth, click 'OK' on the prompt of Bluetooth connection and click 'Agree' for prompt about each smart phone permission.

Check Bluetooth connection: If the Bluetooth symbol in the pull-down menu is green, it means that Bluetooth 4.0 has been connected; if it is blue, it means that Bluetooth 3.0 has been connected; if it is blue in the upper part and green in the lower part, it indicates that both Bluetooth 3.0 and Bluetooth 4.0 have been connected.

Notification setup: On your smart phone, enter 'Setting', 'Application management', 'Fundo' and 'Permission management' sequentially and enable all the permissions there.

After that, enter 'Notification management' and 'Fundo' sequentially and enable all the permissions there. Start 'Fundo', choose 'More', 'Application push notification' and 'Enable run on background' sequentially, enter the application management and choose 'Unrestricted. Click 'Back'. There will be a prompt about enabling automatic start again. Enable automatic start. Click 'Back' and choose the APPs that you want to have synchronous notification, such as QQ, WeChat. The WeChat on your smart phone cannot receive notices when its computer version is on line at the same time. For some smart phones, 'Fundo' needs to be added to the power saving whitelist to avoid being killed on the background when the smart phone battery is low.

Solution for failure of notification: The notification of the smart watch is synchronous with that on your smart phone (this applies to notifications about messages, incoming calls, QQ messages or WeChat messages). Therefore, if there is no such notifications on your smart phone, there will be no such notifications on your smart watch. The solution is entering 'Setting' and 'Notification' on your smart phone, finding out the corresponding APPs and enabling their notification.

Troubleshooting: Different smart phones probably have different Bluetooth protocols and this may result in unstable Bluetooth connection between the smart phone and the smart watch. To solve this problem, disable and enable the Bluetooth of your smart phone , or restore the

defaults of the smart watch. If the smart watch has crashed, press its power button to restart it.

Functions:

Message: For synchronizing the messages on your smart phone (not applicable to IOS smart phones)

Phone book: For synchronizing the contacts on your smart phone

Call history: For synchronizing the call history on your smart phone

Dial: For connecting with your smart phone to make phone calls from the smart watch

Exercise: Click to enter the multi-exercise mode, choose an exercise and click on the screen to start exercising. For each exercise, there are data about duration, calorie consumption, step number, etc. When you want to pause or stop the exercise, click on the screen and choose correspondingly.

Pedometer: It records your step number, calorie consumption and walking distance of each day. At the 12 o'clock each night, it saves the data of that day and resets. Swipe up on the screen to enter the page with options including 'Status' (including 'Enable' and 'Disable'), 'Previous Records' (including the local previous records of the previous days), 'Goal' (for setting the step number of each day) and 'Personal information' (for entering your gender, height, weight and other information for more accurate exercise data).

Electrocardiogram: With help of the optical heart rate technology, the smart watch can get your electrocardiogram about tens of seconds later. After the measurement, letters 'ToAPP' will appear on the screen and the electrocardiogram will be saved on the 'Fundo' APP on your smart phone. You can share your electrocardiograms to others for purpose of reference.

Heart rate monitoring: Make the smart watch fit the wrist well. It would be the best to wear it at the wrist bone's part close to the arm to get your real-time heart rate (usually 80 to 90 times per minute). After the start symbol at the lowest position is clicked, the smart watch will begin to display 'Measuring...' and get your heart rate about 20 seconds later. Swipe down on the screen to enter the

page with options to view the previous heart rates.

Blood pressure: When in blood pressure measurement, put one of your arm flatwise. The smart watch can get your blood pressure about 48 seconds later. Usually, older people have higher blood pressures than younger people and men have higher blood pressures than women.

Sleep monitoring: The smart watch records the duration and quality of your sleep from 9 p.m. to 9 a.m. to help you adjust your work time and rest time to improve your sleep quality. Swipe up on the screen to enter the page with options including 'Status' (including 'Enable' and 'Disable'), 'Previous Records' (including the deep sleep duration and the light sleep duration) and 'Help' (containing detailed directions for use).

• **Excessive sitting reminding:** You can set a maximum sitting duration for the smart watch to sound to remind you automatically upon the maximum sitting duration.

Blood oxygen monitoring: Press 'OK' to enter the blood oxygen monitoring page. Blood oxygen (SPO2H) refers to the oxygen in one's blood (usually 94% to 99%).

Notification: You can view your QQ messages and WeChat messages in time through this function after connecting the smart watch with the 'Fundo' APP on your smart phone.

Music play through Bluetooth: The smart watch can play the music in your smart phone.

Photographing through Bluetooth: When your smart phone is not locked, the smart watch will enter the mode of photographing through Bluetooth and your smart phone will enter the photographing page. Click the smart watch to take pictures. The pictures taken will be saved on your smart phone.

Bluetooth: It is for searching a device to be connected or disconnecting a device that has been connected.

Theme: There are two standby backgrounds to choose.

Calendar: It is for calendar display.

Alarm: You can set five alarms or long press the screen to delete an alarm .

Stop watch: It is for timekeeping of one or multiple times.

Counter: It is for simple calculation.

QR code: There is a QR code. You can download the 'Fundo' APP by using the 'Scan' function with help of your smart phone browser.

Setup: It is for setting the smart watch.

Bluetooth: It is for enabling or disabling Bluetooth.

Clock: It offers 'Clock faces (there are multiple clock faces to choose) and 'Time synchronization' (It is enabled by default. After the smart watch is connected to your smart phone, the time on it and the time on your smart phone will be synchronized. If manual setting of time is needed, disable this function).

Screen on upon message: If this function is enabled, the screen will be on upon any message; however, it consumes a lot of power.

Sound: It is for choosing the ringtones of incoming calls and messages or adjusting the volume of multimedia, ringtones, messages, etc.

Display: It is for adjusting the screen brightness and the backlight-off duration.

Unit: It is for choosing a metric or British system for data units.

Language: The function of automatic synchronization is enabled automatically, so the language on the smart watch will be synchronized according to that on your smart phone after the smart watch is connected with your smart phone. To choose the language manually, disable this function.

Restore defaults: Usually, any software problem can be solved by restoring the defaults.

About: It is for viewing model and software version of the smart watch.

Loss prevention: You can click 'Search' on the smart watch to find your smart phone. In this case, the smart phone will sound an alarm. You can also search the smart watch with the related APP on your smart phone. In this case, the smart watch will sound an alarm.

Gestures: You can turn over the smart watch to mute an incoming call or an alarm clock, or use a gesture (raise your hand) to awaken the system or shake your hand to answer a call.

- **Data transmission:** Download the 'Fundo' APP onto your smart phone. After connection with your smart phone, the smart watch can transmit data about your step number, heart rate, sleep quality and multi-exercise mode to your smart phone. Some data needs to be synchronized manually.

Warranty

1. If the smart watch has any quality problem in normal use due to issues attributable to the manufacturer, such as manufacturing, material or design, we will provide free warranty service of one year following its purchase date.
2. In any of the following circumstances, we will not provide free warranty service.
3. The smart watch fails due to unauthorized disassembling, assembling or refitting;
4. The smart watch fell in use and fails; or
5. The smart watch fails or is damaged due to any artificial damage or any third-party mistake or misuse (such as water entry, cracking by any external force, or scratches on any peripheral component).
6. When applying for the warranty service, please provide the warranty card with the purchase date and the dealer's seal.
7. If the smart watch needs to be repaired, take it to us or any dealer of us.
8. As for all of its functions, please refer to the smart watch you purchased.

Purchase date:

IMEI code:

Shop:

Signature of customer:

Signature of salesperson:

Seal of shop: